



Thank you for purchasing the most advanced Game Management System in the industry. You'll find your new TDP™ ProDealer Buttons™ are a must-have for your Texas Hold 'Em games!

Each button functions as a dealer button, a timer, a visual alert, and more importantly a unification device for game management and multi-table synchronization. You'll find that your button(s) will speed up play and provide a more professional game, whether you're playing a casual hand at home or competing in a small or large Texas Hold 'Em Tournament.

Your ProDealer Buttons are high-quality computing devices with built-in digital timers, visual lighting systems, and wireless communications that allow you to synchronize multiple games on multiple tables, provide simultaneous warnings to all tables that blinds will increase in "1" minutes and to indicate that an event has occurred or will occur! Each button is slightly larger than a normal dealer button and each is made utilizing the highest-quality weighted coating to ensure easy sliding across any poker table. In addition, each button features a tamper-proof design, ergonomic controls and battery casing, and a convenient mini-USB connection to permit easy downloading of game templates from www.TDPro.com. Using MS Windows, you have the ability to download game settings as needed. **(Mini-USB cable is included.)**

Each ProDealer Button is engineered with visual alerts, laser-scripted lettering, manual On/Off and Pause/Reset controls, and a low-battery indicator. Each ProDealer Button comes packaged with instructions, users can also visit our website at www.TDPro.com for additional information, tips, blogs with poker pro's and much more.

Four AAA alkaline batteries are required to get your system up and running. Rechargeable (NiCAD) AAA batteries may also be used. *Batteries should be removed when unit is not in use.* **(Batteries are NOT included.)**

Please Note:

The material in this Users Manual is for informational purposes only. The product(s) described are subject to change without prior notice, due to the manufacturer's continuous development program.

User Instructions:

Congratulations on the purchase of your ProDealer Game Management System™! To get your game management systems up and running, please insert four AAA alkaline batteries into each unit in order to power-up the unit(s).

Inserting Batteries / Powering the ProDealer Button:

1. Each button requires 4 AAA batteries.
2. Remove the battery cover on the bottom of the button case. Insert fingers into the slots and turn to the left to open, right to close.
3. Insert the batteries, aligning the positive (+) and negative (-) terminals as indicated in the battery slots.
4. If one or more Dealer Buttons are purchased, insert batteries and press the On/Off control to power on, the LED indicators will begin flashing yellow, green and red. The words, "Welcome Dealer Master" will appear on the Dealer Button screen identifying the button that will control the game. All other Dealer Buttons will have "Welcome Dealer" displayed on their screens.

Starting the Dealer Buttons:

ProDealer Buttons come pre-loaded with a default template to get you up and running quickly. However, players can choose from a variety of game setting templates by connecting to our website, www.TDPro.com, via the mini-USB connection to create and/or download your preferred game settings.

To start game play:

1. Press the Pause/Reset button one time on the Master Dealer Button to load 1st Round game settings.
2. The LED indicators will begin to flash red and will display the Round Time, Big Blind Amount, Small Blind Amount, and Ante Amount if used.
3. If you are using more multiple Dealer Buttons for the same game, all of the other Dealer Buttons will synchronize to the Master Dealer Button and will display the Round Time, Big Blind Amount, Small Blind Amount, and Ante Amount if used.
4. Press the Pause/Reset button on the Master Dealer Button once again to start play.
5. All buttons will synchronize, all LED indicators will be flashing green, and the Round Time will begin counting down on all of the Dealer Buttons.
Note: The On/Off and Pause/Reset controls on the "Secondary Dealer Buttons" will be disabled while being controlled by the Master Dealer Button.
6. If you need to pause during game play, simply press the Pause/Reset button on the Master Dealer Button once.
7. To resume play, press the Pause/Reset button on the Master Dealer Button once again.
8. Game play will continue.

For help to setup your button(s), go to the www.TDPro.com, CONTACT US (located at the bottom of the web pages), under SUPPORT - select the help video that addresses the area of assistance needed or view them all for a complete overview.

Registering or Downloading Different Game Settings:

1. Using an Internet-capable computer, access our website at www.TDPro.com.
2. Create an account or login to your account if already created.
3. Go to My Account, located at the top of the Login Tab, to register your product using the convenient online form.



- a. You will be emailed instructions on downloading the TDPro Loader software. This software loads the game template from your PC into the attached button.
4. When instructed, plug one end of the Mini-USB cable (**included**) into the Mini USB port on the designated Master Dealer Button and the other end into your computer's USB port.
5. Select "Game Templates" on the website, then select or create a template to download.
6. If creating a new template, enter your game information as directed.
 - a. Click "Submit" to save in the template library.
 - b. Click "Download" to download to your Dealer Button.
 - i. The TDPro Loader Software must be installed on the PC to load the game template into the button(s).
7. Upon message Download Successful, disconnect the mini USB cable from the computer and from the Dealer Button.
8. You are now ready to begin play!

Default Game Settings (Template):

A game template comes on your button(s) and is available immediately for use once batteries are inserted into the buttons. Other game templates may be created or selected from existing templates for downloading into your button(s) by creating and logging into or your account at www.TDPro.com.

Powering Off Your Button(s):

- Press and hold down the On/Off control on the Dealer Button(s) for 3 seconds.
- For maximum battery life; remove at least 1 battery from the button when not in use.

Care and Maintenance of Your Button(s):

- Keep the unit(s) clean. Wipe clean with a damp (not wet) cloth.
- Dry carefully with a soft, dry towel.
- Do not clean with alcohol or abrasive materials, such as steel wool or cleaning chemicals.
- Store the unit(s) in a cool, dry place.
- Do not store in damp environments or in "non-breathable containers" such as plastic bags or damp gym bags.
- Do not store unit(s) with conductive material, such as a wet towel.
- Do not store or use the button(s) around strong magnets.
- Protect the unit(s) from extreme cold or heat.
- Do not expose to direct sunlight for long periods of time, such as leaving unit(s) in a car, or in extreme temperature conditions, these may cause your buttons to warp and/or the displays to lose luminosity.

Unauthorized accessing or servicing any internal parts of your button(s) can cause damage and will void all warranties.

TD Pro's Limited Guarantee:

TDPro LLC issues this limited ProDealer Button guarantee to consumers who have purchased this product from an authorized seller.

TDPro LLC guarantees to the original consumer of this product that the product will be free from defects in material or workmanship for 90 days from the date of purchase. Please retain the seller receipt, which is your proof of purchase. This guarantee does not cover batteries, damages due to misuse or abuse, accidents, non-compliance with published precautions; improper maintenance, commercial use, or cracked/broken cases. This guarantee does not cover any damages, losses, costs or expenses; direct, indirect, incidental, consequential or special; arising out of, or related to, the product. During the guarantee period, the product will be either repaired or replaced at an authorized service center at no charge, at the discretion of TDPro. This guarantee does not affect the consumer's statutory rights under applicable national or state laws in force, or the consumer's rights against the dealer arising from their sales/purchase contract.

Please Note:

The material contained herein is for informational purposes only. The products described are subject to change without prior notice, due to the manufacturer's continuous development program.

ProDealer Privacy Policy:

This Privacy Statement has been prepared by TDPro, LLC; host and operator of ProDealer Buttons. TDPro, LLC operates a variety of Web sites including www.ProDealerButtons.com and www.TDPro.com, and is committed to protecting the privacy of our website users and Dealer Buttons members. To that end, we offer this Privacy Policy to inform our Members and Users of how we collect, use and disclose your personal information. TDPro, LLC will take reasonable steps to protect your personal information in accordance with this Privacy Policy and applicable laws. To make this information easily accessible, we provide a link to our policy at the bottom of most of the pages in our Web site.

Visit www.TDPro.com for full information on:

- Warranty and Returns
- FCC Statements of Compliance
- Support/Contact Us